

# berlin

METROPOLIS<sup>®</sup>  
MADE IN ITALY



**berlin 1**



**berlin 2**

Preparing the substrate: Clean the substrate and use Factor to correct any unevenness.  
Apply 1 coat of Metro Fix water-based fixative.

	Step	Product	Consumption	Technique
<b>BERLIN 1</b>	1	<b>factor</b>	1,25 kg	Use a Stainless Steel Pollock Trowel to apply an even coat of Factor. Create the chipped effect while the product is still wet, by dabbing the surface using a Dali Sponge and then scratching it with a Mondrian Pad. After 10'-15' spray with water and smooth the surface using a trowel for an even effect.
	2	<b>hot metal</b>	0,1l	Once dry, use a Magritte Roller to apply a coat of Hot Metal and dab the surface unevenly with a Dali Sponge to vary the effect.
	3	<b>lady vi</b>	0,1l	Once dry use a Klimt Brush to apply a coat of Lady Vi and tone down with a Dali Sponge.
<b>BERLIN 2</b>	1	<b>factor</b>	1,25 kg	Use a water-base fixative to glue scraps of foil using a Klimt Brush. Once dry, use a Stainless Steel Pollock Trowel to apply an even coat of Factor leaving portions of the foil exposed and scratch the wet surface with a Mondrian Pad
	2	<b>hot metal</b>	0,1l	Use a Magritte Brush to apply a coat of Hot Metal and tone down with a Dali Sponge until obtaining the desired effect.
	3	<b>lady vi</b>	0,1l	Apply a coat of Lady Vi with a Klimt Brush then tone down with a Dali Sponge.