

# harlem

METROPOLIS<sup>®</sup>  
MADE IN ITALY



Preparing the substrate: Clean the substrate and use Factor to correct any unevenness.  
Apply 1 coat of Metro Fix water-based fixative.

	Step	Product	Consumption	Technique
<b>HARLEM 1</b>	1	<b>factor</b>	1,25 kg	Apply 1 even coat of Factor with a Stainless Steel Pollock Trowel and create the netted effect by repeatedly pressing Armatex C1 Mesh. Once dry, lightly sand any rough spots.
	2	<b>money</b>	0,07 l	Apply an even coat of Money with a Magritte Roller.
	3	<b>hot metal</b>	0,1 l	Apply a glazing coat of Hot Metal with a Dali Sponge.
<b>HARLEM 2</b>	1	<b>factor</b>	1,25 kg	Apply an even coat of Factor with a Pollock Trowel creating a scratched effect by rippling the surface with criss-cross trowel. After 10'-15' spray with water and smooth the surface with a Pollock Trowel.
	2	<b>acqua.dolce</b>	0,07 l	Apply a coat of Acqua.Dolce with a Klimt Glazing Brush evenly and use a wet Dali Sponge.
	3	<b>money</b>	0,1 l	Once dry, use a Klimt Glazing Brush to apply a coat of Money in the ripples, use a wet Dali Sponge to add a different effect.