

# manhattan

METROPOLIS<sup>®</sup>  
MADE IN ITALY



Preparing the substrate: Clean the substrate and use Factor to correct any unevenness.  
Apply 1 coat of Metro Fix water-based fixative.

	Step	Product	Consumption	Technique
<b>MANHATTAN 1</b>	1	<b>factor fine</b>	1,25 kg	Use a Stainless Steel Pollock Trowel to apply an even coat of Factor Fine. Create the lined effect with vertical strokes using a Mondrian Decorative Trowel. After 10'-15', spray with water and smooth the surface using a trowel for an even effect.
	2	<b>lady vi</b>	0,1l	Once dry, use a Klimt Glazing Brush to vertically apply a coat of Lady Vi following the streaks.
<b>MANHATTAN 2</b>	1	<b>factor fine</b>	1,25 kg	Use a Stainless Steel Pollock Trowel to apply an even coat of Factor Fine. Create the dotted effect rotating the Warhol Decorative Pad while the product is still wet. After 10'-15' spray with water and smooth the surface using a trowel to obtain an even effect.
	2	<b>lady vi</b>	0,1l	Once dry, use a Klimt Glazing Brush to apply an even coat of Lady Vi trying to avoid leaving brushstrokes signs.