



Preparing the substrate: Clean the substrate and use Factor to correct any unevenness.  
Apply 1 coat of Metro Fix water-based fixative.

	Step	Product	Consumption	Technique
<b>JAKARTA 1</b>	1	<b>factor</b>	1,25 kg	Use a Stainless Steel Pollock Trowel to apply an even coat of Factor. Create the round effect with rotating strokes using a Mondrian Pad. After 10'-15' spray with water and smooth the surface using a trowel for an even effect.
	2	<b>money</b>	0,07 l	Use a Magritte Roller to apply an even coat of Money.
	3	<b>hot metal</b>	0,1 l	Use a Dali Sponge to apply an uneven glazing coat of Hot Metal to give an antique effect.
<b>JAKARTA 2</b>	1	<b>factor</b>	1,25 kg	Use a Stainless Steel Pollock Trowel to apply an even coat of Factor. Create the chipped effect by dabbing the surface using a Dali Marine Sponge while the product is still wet. After 10'-15', spray with water and smooth the surface using a trowel for an even effect.
	2	<b>hot metal</b>	0,1 l	Use a Magritte Roller to apply an even coat of Hot Metal .
	3	<b>money</b>	0,07 l	Use a Dali Sponge to unevenly apply a glazing coat of Money leaving chipped portions exposed.