



istanbul 1



istanbul 2

Preparing the substrate: Clean the substrate and use Factor to correct any unevenness.
Apply 1 coat of Metro Fix water-based fixative.

	Step	Product	Consumption	Technique
ISTANBUL 1	1	factor	1,25 kg	Use a Stainless Steel Pollock Trowel to apply Factor, create the chipped effect, while the product is still wet, with diagonal roller strokes using a Degas Roller. After 10'-15' spray with water and smooth the surface using a trowel.
	2	money	0,07l	Use a Magritte Roller to apply an even coat of Money.
	3	soul cement	0,66 kg	Once dry, use a Gauguin Trowel to apply an uneven coat of Soul Cement leaving visible portions of the previous coat, following the streaks to create the characteristic veining.
ISTANBUL 2	1	factor	1,25 kg	Use a Stainless Steel Pollock Trowel to apply an even coat of Factor. Create the chipped effect by dabbing the surface using a Dali Sponge. After 10'-15' spray with water and smooth the surface using a trowel.
	2	money	0,07l	Use a Magritte Roller to apply an even coat of Money.
	3	soul cement	0,66 kg	Use a Stainless Steel Pollock Trowel to apply an uneven coat of Soul Cement leaving visible portions of the previous coat.